

Instructions on recording using ZOOM H2 recorder.

Recorders can be used in a wall outlet with supplied adapter or with 2AA batteries.

#### USING THE MENU

To access the menu, press the MENU key.

Use the track forward and backward keys to scroll up and down the menu.

Use the REC key (red dot) to make your selection.

To exit the menu, press the MENU key.

#### RECORDING

Each 1GB card can hold 7 hours of audio in MP3 format.

To ensure the best quality, set the recording mode to MP3 320 kbps by pressing MENU → REC MODE → MP3 320kbps

#### RECORDING A ONE-ON-ONE INTERVIEW

Set MIC GAIN (on side of unit) to H

Set the mic panel (using the arrows above the MENU key) to FRONT 90 degrees.

Attach the mic stand (or handheld device) and place the recorder so that the FRONT is facing the source.

#### RECORDING AN ACTIVITY OR GROUP OF PEOPLE

Set MIC GAIN (on side of unit) to M

Set the mic panel (using the arrows above the MENU key) to REAR 120 degrees.

Attach the mic stand (or handheld device) and place the recorder so that the REAR is facing the source.

#### RECORDING OUTDOORS

Put the supplied windscreen over the mic.

Use the MENU to turn on LO CUT. (Make sure to turn it off when you go back indoors)

#### START RECORDING

Press REC key (red dot) and red light will flash (recorder is on standby).

Use track forward and backward keys to set REC LEVEL – 100 is standard but you can adjust lower or higher.

Press REC key again and light stays lit (unit is recording)

Press REC key to stop recording.